

MOBILE SECURITY LOCKING CASE

The Travel Safe

Your new resettable combination lock is preset to open at 0-0-0-0.
(Even though the dials may be positioned at other numbers)

To detach Lock and Cable Unit and to unlock Security Cable –

1. With the lock set to the opening combination, press the Black Release Button and pull the Lock and Cable Unit apart from the Lock Case Nozzle. (See Fig. 1)
2. While pressing the black release button, slide the Hidden Lock Tab sideways to unlock the Cable Bullet End from the Cable Locking Port. (See Fig.1)

Note: The Cable Bullet End may pop out quickly when unlocking. Please keep the Lock and Cable Unit at least 8" away from you when unlocking the Cable Bullet End.




Fig. 1




Fig.2

To Reset Your Combination –

1. With the Lock and Cable Unit apart from the Lock Case and the Cable Bullet End released, use a screwdriver to press the Reset Button inward and turn it 90° clockwise. (See Fig. 2)
2. Turn the Dials to your desired combination, then turn the Reset Button 90° counter-clockwise back to its original vertical position.

3. Your lock is now ready to open with your own personal combination. Keep your combination in a safe place and accessible for future reference.

To Load and Lock The Travel Safe

1. Detach the Lock and Cable Unit from the Lock Case Nozzle and release the Cable Bullet End from the Cable Locking Port. (Fig. 1.)
2. Fasten the security cable around an immovable object and insert the Cable Bullet End back into the Cable Locking Port until it clicks.
3. Open the Travel Safe and put in your personal item to be secured. (Fig. 3.)
4. Press the Black Release Button and Push the Lock and Cable Unit back into the Lock Case Nozzle until it clicks.
5. Scramble the combination dial to lock.



Fig. 3



Locked to beach chair.

Now you can lock up your...

- Digital camera
- MP3 player
- Cell phone
- Passport
- Keys
- Money
- ...anything!

Lock your Travel Safe to a...

- Beach chair
- Suitcase interior
- Closet pole
- Bed frame
- Desk
- ...anywhere!